


<b>Parts List No.</b> 545164320		 <b>PARTS LIST</b>	<b>MODEL</b> MAC GBV 325 (RoW,EU,A U, RUSS IA)
<b>Date</b> 10/01/12	<b>Replaces</b> 545164320 - 8/02/12		<b>NOTE :</b> Illustration may differ from actual model due to design changes.

**TYPE 1,2,3,4**




**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	-----	Decal - Engine Cover	22.	545100801	Door- Vac
✓	*****	<b>TYPE 1</b>	23.	545115601	Spring - Vac Door
	545002941	<b>TYPE 2,3</b>	24.	545003502	Screw
✓	580779501	<b>TYPE 4</b>	25.	530016406	Screw - Handle Vac
2.	530015814	Screw	26.	-----	Decal - Warning
3.	545135806	Assy - Engine Cover	✓	*****	<b>TYPE 1</b>
4.	530015880	Screw		577924201	<b>TYPE 2,3</b>
5.	545134001	Shield - Baffle	✓	580863201	<b>TYPE 4</b>
6.	545099101	Baffle	27.	530092322	Washer - Lock
7.	530016391	Screw	28.	545109901	Washer - Impeller
8.	545081852	Kit - Starter Pulley	29.	580780901	Assy-Impeller
9.	545213601	Spring - Starter	30.	-----	Spacer - Flywheel
10.	545107101	Tube - Starter Rope	✓	*****	<b>TYPE 1</b>
11.	530054834	Handle - starter		545113701	<b>TYPE 2</b>
12.	545081833	Kit - Rope		576810101	<b>TYPE 3,4</b>
13.	545081830	Kit - Switch (momentary) (Incl. 14)	31.	-----	Locknut
14.	545128201	Protector - Switch	✓	*****	<b>TYPE 1</b>
15.	545099001	Bearing		530015515	<b>TYPE 2,3,4</b>
16.	530626605	Nut	32.	530015197	Nut
17.	-----	Decal - Start	33.	530016386	Screw
✓	*****	<b>TYPE 1</b>	34.	574882502	Assy-Scroll Assy. RH (Incl. 15)
	545165955	<b>TYPE 2,3</b>	35.	545101201	Handle - Vac
✓	580863702	<b>TYPE 4</b>	36.	576764901	Assy - Fuel Tank (Incl. 38,39,40)
18.	545113802	Trigger - Throttle	37.	530095646	Assy - Fuel Pickup
19.	574695403	Assy - Scroll LH (Incl. 22,23)	38.	530069247	Kit - Fuel Line (carb/purge)
20.	530015814	Screw	39.	530069216	Kit - Fuel Line (tank/purge)
21.	-----	Decal - Vac Door	40.	530057973	Assy - Fuel Cap w/retainer
✓	*****	<b>TYPE 1</b>	41.	530016445	Screw - Fuel Tank Retainer
	545002942	<b>TYPE 2,3</b>			
✓	580781501	<b>TYPE 4</b>			

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)



**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.


Ref.	Part No.	Description	Ref.	Part No.	Description
1.	525592801	Assy - Muffler (Incl. 2,3,4)	23.	530015162	Retainer - Wrist Pin
2.	530058982	Bolt	24.	545081865	Kit - Assy. Connecting Rod
3.	-----	Gasket (Ref.#40)	25.	545158001	Module - Ignition
4.	545098801	Shield - Muffler Heat	26.	530016357	Screw
5.	545115301	Cylinder	27.	545127601	Assy - Wire Harness
6.	530015953	Bolt	28.	-----	O-Ring (Ref.#40)
7.	952030249	Spark Plug (RCJ-6Y)	29.	530015828	Washer
8.	545084901	Adapter - Carb.	30.	-----	Assy - Flywheel
9.	530016441	Screw	✓ ★★★★★	545197301	<b>TYPE 1</b>
10.	545115501	Linkage - Throttle	530054115		<b>TYPE 2</b>
11.	545081855	Kit - Carb. Assy (WT875A) (Incl. 12,18)	31.	530015941	Retainer - Crankshaft
12.	545157103	Lever- Choke (Red)	32.	530055728	Bearing - Outer
13.	545112602	Base - Airbox	33.	530019264	Seal
14.	530016429	Screw	34.	530032125	Bearing - Inner
15.	545116801	Filter	35.	530012582	Assy - Crankcase (Incl. 32,33,34)
16.	545112702	Cover - Air Box Filter	36.	-----	Assy - Crankcase & Crankshaft (Incl. 31,35)
17.	-----	Decal - 1/2 choke	✓ ★★★★★	545102102	<b>TYPE 1</b>
✓ ★★★★★	545165907	<b>TYPE 1</b>	579012701		<b>TYPE 2</b>
✓ ★★★★★	580863301	<b>TYPE 2,3</b>	37.	-----	<b>TYPE 3,4</b>
18.	530035497	Bulb - Purge (walbro 188-16)	38.	530057954	O-Ring (Ref.#38,40)
19.	-----	Gasket (Ref.#40)	39.	530016386	Assy - Rear Plug (Incl. 37)
20.	-----	O-Ring (Ref.#40)	40.	545081832	Screw
21.	545081864	Kit - Piston / Connecting Rod (Incl. 22,23,24)			Kit - Gasket (Incl. 3,19,20,28,37)
22.	545154009	Ring - Piston			

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545164320		 <b>McGULLOGH PARTS LIST</b>	<b>MODEL</b> MAC GBV 325 (RoW,EU,A U, RUSS IA)
<b>Date</b> 10/01/12	<b>Replaces</b> 545164320 - 8/02/12		<b>NOTE</b> : Illustration may differ from actual model due to design changes.

**TYPE 1,2,3,4**



**⚠ WARNING**

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description
1.	545099401	Tube - Upper Vac
2.	545144101	Screw
3.	530402633	Decal - Screw
4.	545141001	Tube - Lower Vac
5.	575873501	Tube - J
6.	530095564	Assy - Vac Bag
7.	545167801	Tube - Upper Blower w/barrier
8.	545100601	Tube - Lower Blower
9.	545151201	Nozzle - High Speed

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545164320		 <b>McGULLOGH PARTS LIST</b>	<b>MODEL</b> MAC GBV 325 (RoW,EU,A U,RUSSIA)
<b>Date</b> 10/01/12	<b>Replaces</b> 545164320 - 8/02/12		<b>NOTE :</b> Illustration may differ from actual model due to design changes.

**\*\*\*\*\* Service Reference \*\*\*\*\***

Note : Please refer to the TYPE NUMBER and SKU NUMBER on your unit and order the parts below.

Ref.# 1 - Page 1 - Decal - Engine Cover

(SKU# 952715703 Type 1 - Use 545002941 decal)

(SKU# 952715735 Type 1 - Use 545002941 decal)

(SKU# 967167101 Type 1 - Use 580779501 decal)

Ref.# 17 - Page 1 - Decal - Start

(SKU# 952715703 Type 1 - Use 545165955 decal)

(SKU# 952715735 Type 1 - Use 545165955 decal)

(SKU# 967167101 Type 1 - Use 580863702 decal)

Ref.# 21 - Page 1 - Decal - Vac Door

(SKU# 952715703 Type 1 - Use 545002942 decal)

(SKU# 952715735 Type 1 - Use 545002942 decal)

(SKU# 967167101 Type 1 - Use 580781501 decal)

Ref.# 26 - Page 1 - Decal - Warning

(SKU# 952715703 Type 1 - Use 577924201 decal)

(SKU# 952715735 Type 1 - Use 545052802 decal)

(SKU# 967167101 Type 1 - Use 580863201 decal)

Ref.# 30 - Page 1 - Spacer - Flywheel

(SKU# 952715703 Type 1 - Use 545113701 spacer)

(SKU# 952715735 Type 1 - Use 545113701 spacer)

(SKU# 967167101 Type 1 - Use 576810101 spacer)

Ref.# 31 - Page 1 - Locknut

(SKU# 952715703 Type 1 - N/A)

(SKU# 952715735 Type 1 - N/A)

(SKU# 967167101 Type 1 - Use 530015515 locknut)

Ref.# 17 - Page 2 - Decal - Start Position

(SKU# 952715703 Type 1 - Use 545165907 decal)

(SKU# 952715735 Type 1 - Use 545165907 decal)

(SKU# 967167101 Type 1 - Use 580863301 decal)

Ref.# 30 - Page 2 - Assy - Flywheel

(SKU# 952715703 Type 1 - Use 545197301 flywheel)

(SKU# 952715735 Type 1 - Use 545197301 flywheel)

(SKU# 967167101 Type 1 - Use 530054115 flywheel)

Ref.# 36 - Page 2 - Assy - Crankcase & Crankshaft

(SKU# 952715703 Type 1 - Use 545102102 assy. crankcase)

(SKU# 952715735 Type 1 - Use 545102102 assy. crankcase)

(SKU# 967167101 Type 1 - Use 579012701 assy. crankcase)